





ACURA INSTALLATION INSTRUCTIONS	Accessory HALOGEN FOG LIGHTS P/N: 08V31-SP1-202	Application 1994 - 95 LEGEND 2-DOOR	Publications No. BJI 16119-16551 Issue Date SEP 1994

PARTS LIST


2 Fog lights



Right bracket



Left bracket



6 Washer-screws
(5 x 16 mm)



2 Spring nuts



8 Self-tapping screws
(5 x 12 mm)




Fog light harness



Fuse (15A)




Headlight relay




Fog light relay




Switch harness



11 Wire ties



Fuse label



Right trim



Left trim




Ground bolt



Fog Light Switch (sold separately)


L Model

P/N: 08V31-SP0-200G



LS Model

P/N: 08V31-SP0-200H

**TOOLS AND SUPPLIES REQUIRED**

Phillips screwdriver



Flat tip screwdriver

8 mm and 10 mm Combination wrenches


INSTALLATION**Before You Begin:**

- Write down the customer's radio station presets; the radio memory will be erased when you disconnect the battery.
- If the radio has a coded theft protection circuit, be sure you have the anti-theft code before you disconnect the battery.
- A fog light switch is required to install the fog lights; it is sold separately. Have the recommended fog light switch on hand at the time of installation.


1. Disconnect the negative cable from the battery.
2. Remove the grille covers from the front bumper.




3. Remove the driver's side front turn signal (one screw, one connector).




4. Route the fog light harness along the car's wire harness, and plug the connectors:
- 1-pin connector – Plug into the 1-pin connector taped to the left turn signal with blue tape.
 - Ground terminal – Tighten with the ground bolt from the kit as shown.
 - Secure the fog light harness to the car's wire harness with seven wire ties.



5. Slide a spring nut over each of the four holes in the front bumper. Attach the fog light bracket to the front bumper using the four self-tapping screws.




6. Plug in the fog light connector; then position the fog light on the bracket, and install three washer-screws.




Routing the Wire Harness Inside the Car


7. Remove the courtesy light switch.



8. Remove the driver's side lower cover (three screws).




9. Remove the driver's side kick panel.




KICK PANEL

10. Stick the fuse label to the back of the kick panel in the location shown.



FUSE LABEL

11. Unplug the 14-pin connector of the car's wire harness from the connector holder. Plug the 14-pin connectors of the switch harness into the connectors just unplugged.




CONNECTOR HOLDER

CAR'S WIRE HARNESS (GRAY CONNECTOR)

14-PIN CONNECTOR SWITCH HARNESS

12. Remove the bolt holding the connector holder. Install the headlight and fog light relays with the connector holder using this bolt. Check that the relays do not interfere with the steering column, and tighten the bolt securely. Plug the 6-pin and 4-pin connectors of the switch harness into the relays.



CONNECTOR HOLDER

4-PIN CONNECTOR

HEADLIGHT RELAY


8 mm BOLT

6-PIN CONNECTOR SWITCH HARNESS

13. Plug the remaining connectors of the switch harness:

- A 1-pin connector – Plug into the No. 5 connector of the fuse box.
- B 1-pin connector – Plug into the 1-pin connector taped to the wire harness at the fuse box.
- C 2-pin connector – Plug into the 2-pin connector taped to the wire harness at the fuse box.
- D Fuse – Press into position in the fuse box.


14. Use a wire tie to secure the 2-pin coupler (Red, Red/Black) and switch harness to the car's wire harness.



The 1-pin connector (Blue/Red) is taped on the vehicle pre-harness located behind the foot rest. To find this connector, use a flat tip screwdriver to remove the foot plate; then remove the foot rest.



- 15. Route the courtesy light and switch harness down through the opening in the lower cover, and plug in the switch harness.

L Model:



LS Model:


- Using a small flat tip screwdriver, release the lock on the 10-pin green connector of the car's wire harness.
- Press the three terminals of the sub-cord into the 10-pin connector as shown. Note the sizes and colors of the three terminal wires when plugging the wires into the 10-pin green connector.
- Connect the 8-pin connector of the switch harness to the 8-pin connector of the sub-cord.




- 16. Reinstall the lower cover.
- 17. Reinstall the kick panel.

Aiming Adjustment

- 18. Adjust the aiming according to local laws and regulations. To adjust, turn the adjusting screw in or out until the correct aiming is obtained.




- 19. Install the fog light trim.



- 20. Connect the negative cable to the battery.
- 21. Enter the customer's radio anti-theft code, if applicable, and reset the radio station presets.
- 22. Reset the clock.

How to Operate Fog Lights

1. To turn on the fog lights, press the fog light switch with the light switch set to "●" and the headlights in low beam. When you press the fog light switch, the pilot indicator on the switch comes on.



2. To turn off the foglights, do any of these:

- Press the fog light switch again.
- Put the headlights on high beam.
- Turn off the headlights when the car is stopped.


NOTE: The fog light lenses may cloud due to changes in the outside temperature; this is normal and should go away in warm weather.

Lens or Bulb Replacement


NOTE:

- Use only a genuine ACURA halogen light bulb of the specified wattage.
- Do not touch the bulb. Oily or greasy substances on the bulb can shorten its service life due to the heat produced when the bulb is turned on. If the bulb is accidentally touched, wipe it clean with a clean soft cloth that has been dampened with a denatured alcohol or a mild detergent solution.


1. Remove the fog light trim.



2. Remove the fog light (three screws, one connector).




- Remove the three screws that fasten the rear cover and remove the rear cover.



If you are only replacing a broken fog light lens, go to step 7; otherwise, continue with step 4.


- Release the spring from the hook and pull the socket out of the housing.




- Unplug the terminal of the socket wire from the terminal of the light harness.
- Replace the bulb with a new one.

If you are only replacing the fog light bulb, go to step 11; otherwise, continue with step 7.

- Using a T10 Torx driver (tamper resistant), disassemble the fog light, and discard the broken lens.




- Check the housing, retainer, reflector, and bulb cover for debris. Use a sponge or cloth and a solution of mild liquid dishwashing soap and water to clean any debris.
- Remove and replace the rubber seals on the retainer and the reflector.




10. Reassemble the fog light using a new lens:

- Align the cutout in the lens with the cutout in the retainer.
- Make sure the rubber seals are seated properly and are not twisted or pinched.
- Tighten the four screws in a crisscross pattern.



11. Align the cutout in the socket with the locating tab on the fog light housing when installing the socket.



12. Slide the terminal cover over the connectors, and press it into position between the two retaining pins.


- Check that the wires are not forced against any metal parts.
- Check that the wires are not pinched between the rear cover and the fog light housing when reinstalling the rear cover.
- Check that the gasket is installed properly and not twisted or inverted.
- Tighten the rear cover screws securely.

13. Reinstall the fog light.


SPECIFICATIONS


Bulb: 12V-55 W H3 bulb
(P/N: 33165-SB0-7310)

Fuse: 15A
(P/N: 98200-31500)



B	BLACK	BR	BROWN
Y	YELLOW	O	ORANGE
L	BLUE	SB	SKY BLUE
G	GREEN	LG	LIGHT GREEN
R	RED	P	PINK
W	WHITE	GR	GRAY


L MODEL


LIGHT SWITCH

FOG LIGHT SWITCH	OFF	-	-	-	-
	ON	-	-	ON	-